

MAKESIGNS.COM

Window Static Cling Material - Installation Instructions

What you'll need:

- Water
- Rag, sponge, or spray bottle
- Mild dish soap (like Palmolive)
- Glass cleaner
- Straight edged object that is firm but not sharp (rubber window squeegee is recommended)

Soap Solution:

- Mix a ½ tablespoon of mild dish soap per one cup water.
- Mix well in spray bottle.



Large signs are easier to hang with 2 people... one to position top of the sign and one to pull the backing off.

1. Clean the **inside** of the window with glass cleaner and a rag.
2. **Generously** spray soapy solution on the window.
3. Pull the backing off of the top third of the Static Cling material and apply to the **inside** of the window.
4. With your squeegee (or straight edged object), firmly press the solution out of the top third of the material.
5. With the top third of the material applied to the window, pull the rest of the backing off of the material.
6. With the backing off, pull the remaining two thirds of the material away from the window. Take your squeegee and gradually press the solution out from top to bottom until the sign is totally flat and bubble free. If any air bubbles occur, pull the material back a bit and repeat this step.
7. Wipe down window for a clean finish.



If any bubbling occurs, just pull the material back a bit and reapply with your squeegee.



Helpful Hints...

If you use water instead of the Palmolive/water mixture, the material will not be as easy to handle during installation and some ink residue may be left behind on the window when the sign is removed.

Note: If at anytime the material becomes “unmanageable”, apply more soap solution to the window. The more solution that is on the window, the easier it will be to manage the material and apply it.

*Temperature of the intended surface should be between 45 and 90 degrees Fahrenheit for best results